

SOLVIT™
PRODUCTS
Net Pet Barrier
Care & Use Guide

Congratulations on the purchase of your new Solvit Products Net Pet Barrier. This Barrier is designed for installation behind the front or rear seat in all vehicles.

The carton should contain: a storage pouch; a large netting section; and a fastening kit which includes seven circular fasteners with cord attached, seven square fasteners with adhesive backing, and seven spring-loaded barrel locks. Please note only six of the fastener sets are needed to install the Barrier. We suggest storing the extra set in the storage pouch or some other safe place.

The netting section is attached to a wire frame which “pops open” automatically. Take care when removing the netting section from the storage pouch.

INSTALLATION:

Step 1: The square fasteners must be attached to the plastic covers on the vertical columns which separate the windows - three fasteners per side - either behind the front seat or behind the back seat. **IMPORTANT:** the square fasteners must be attached to a super-clean surface (see below).



The approximate position to adhere the three square pieces is: 1) at the highest point on the plastic cover, or about 5 inches below the headliner, whichever is lower; 2) eight inches below the first fastener; and 3) eight inches below the second fastener. Vehicle dimensions vary widely - therefore, to determine the exact position to adhere the fasteners, we recommend holding the netting section in place by hand, centered in the vehicle and behind the seat, with the top of the wire frame flush with the headliner. Now stretch the side panels of the netting section out until they reach the plastic covers (this is easier with two people). Please note the netting section is large enough to fit the widest vehicles; therefore, the side panels might not extend fully before touching the plastic covers – this is normal for most vehicles! Mark with a pencil where each of the grommet strips touches the plastic cover. The three marks on each side of the vehicle should be “mirror images” (same height, same forward position).

VERY IMPORTANT!! On and around each of the six pencil marks, clean a two-inch square area **THOROUGHLY** with rubbing alcohol. Repeat this cleaning step **THREE TIMES** to make sure the surface is ready. If the temperature in the vehicle is less than 70°F, it will be necessary to heat the plastic area where the 3M square fasteners will adhere. Using a hair dryer, warm the area for approx. 60 seconds until very warm to the touch. Working one at a time, peel the backing off the fasteners and press firmly against the plastic where it has been cleaned. Once all six fasteners are in place, wait overnight before installing the netting section. Store the extra square fastener in a safe place.

Step 2 (next day): To attach the six round fasteners to the netting section, thread the cord from each fastener through the outermost grommet hole on each of the six grommet strips, and slip a spring-loaded barrel lock onto each cord. Store the extra round fastener and barrel lock in a safe place.

Step 3: Hold the netting section in place in the vehicle so the two pieces of “hook” tape along the bottom of the wire frame are facing toward the front. Press each of the round fasteners against its respective square fastener until all six fastener sets are connected.

Most likely, it will be necessary to adjust the location of the barrel locks on the fastener cords to achieve the best fit. On narrower vehicles, the cords might need to be threaded through two or more grommets to get the best fit. In this case, the netting on the side panels will gather in a fan-fold pattern when the barrel locks are tightened. This keeps the material neat and out of the driver’s vision. If necessary, excess cord can be kept out of the way by tying it in a loose knot or bow.



The hook tape strips along the bottom of the wire frame will adhere to most automotive carpet. Press the strips into the carpet on the back of the seats (if applicable) to further stabilize the barrier.

Once adjusted for the correct fit, the Net Pet Barrier can be un-installed and re-installed quickly and easily. To un-install, carefully pull each of the round fasteners off the square fasteners, grab the short sides of the wire frame with both hands, and twist (one hand clockwise, the other counter-clockwise) so the wire frame will “fold” into three loops which align together. Slip the net in this position into the provided pouch for storage. To reinstall, carefully remove the “folded” net from the pouch taking care the wire frame does not “pop open” unintentionally. Reposition the netting section in the vehicle, press the round and square fasteners together and adjust the barrel locks, if necessary.



PLEASE NOTE: The Net Pet Barrier is designed to keep a well-behaved pet off the seat in front. It will not restrain a large, aggressive, untrained pet. Small holes caused by pet contact with the net do not generally affect the usefulness of the Barrier and are not covered under warranty.

Warranty: The Net Pet Barrier is warranted to be free from defects in materials or workmanship for a period of one (1) year from date of purchase. A copy of the original sales receipt is required for warranty issues.

SOLVIT Products is dedicated to offering innovative solutions to improve pets’ quality of life. Please feel free to contact us with any questions, comments, or warranty issues. Thank you for your purchase!

(This document available with color images on our website)